


Mousy Quick Start Guide


1

Mousy is charged using the microUSB port located on the bottom. Any USB charger can be used with the supplied cable. When charging, the red light will pulse slowly. The green led will turn off when charging is complete. Mousy ships fully charged.




2

To add a tail to Mousy simply clip or tie it to the provide loop on the rear of Mousy.




3

Mousy will run in auto mode when turned on and no connection to the GoKittyCat app is found. In auto mode Mousy will move randomly until an obstacle stops it. Mousy will then randomly change its direction




4

Install the GoKittyCat app. The app can be located by searching for "GoKittyCat" without the quotes and with no spaces.



5

Launch the GoKittyCat app. Then press the connect button located on the bottom of Mousy. The green light will illuminate. Then press the connect button on the GoKittyCat app.



6

Once connected a timer for auto play can be set. Mousy will turn off once the timer runs out. Mousy can be manually controlled by selecting Manual Control.

